

**BUSH KNIFE STAINLESS STEEL
ITEM NO.: 45083**



Manual for use

Read this manual carefully before use.

Use

The machete is ideal for removing smaller branches, trees or logs, peeling bark from logs and cutting branches from the trunk, in forestry and gardening. Also, for use in hiking, fishing, camping, etc.

Do not abuse the machete as a tool, e.g., for prying objects such as a crowbar. This will damage the blade. The blade will be bend and even break off.

Technical data

Manufactured with stainless steel. The length of the machete is 43 cm and length of the handle is 14 cm.

Care Instructions

- After each use. thoroughly clean the blade from dirt and dry the blade
- Never expose the machete to extreme heat while drying. This will cause distortions and cracks on the handle may shrink.
- Lightly tub the entire blade with suitable oil.
- Please refer to specialist literature for sharpening the blade with a sharpening steel, smoothing the blade on an oilstone and for the treatment with sharpening oil.
- Never grind the blade on an emery stone. The blade will burn and become damaged.
- Do not use for people and alive animals.
- Keep away from the child.
- Careful touch by hand (easy to hurt)