

Návod k použití
Nůž bezpečnostní kovový s krytou čepelí
Položka č.: 16058




Před použitím si pečlivě přečtěte tento manuál.

Popis

- bezpečnostní nůž s krytou čepelí pro bezpečné otevírání kartonů bez poškození vnitřního obsahu, snadné a bezpečné přerézání pásek apod.
- masivní kovová konstrukce s gumovými ergonomickými prvky pro snadnou a bezpečnou práci
- náhradní čepel: pol. č. 16074

Způsoby použití



Bezpečnostní pokyny

- přečtěte si tento manuál před prvním použitím a uschovejte ho pro další použití
- držte nůž pevně, proveďte hladký a kontrolovaný pohyb
- vždy používejte nůž na určený účel, nepoužívejte ho na materiály, pro které není určen
- pravidelně vyměňujte čepel, aby byla ostrá a účinná
- zabraňte dětem k přístupu k noži

Instructions for use
Metal safety knife with a covered blade
Item No.: 16058




Read manual carefully before use.

Description

- safety knife with a covered blade for safe opening of cartons without damaging the internal contents, easy and safe cutting of tapes, etc.
- solid metal construction with rubber ergonomic elements for easy and safe work
- spare blade: item No. 16074

Methods of use



Safety instructions

- read this manual before first use and keep it for future use
- hold the knife firmly, make a smooth and controlled movement
- always use the knife for its intended purpose, do not use it on material for which is not intended
- replace the blade regularly to keep it sharp and effective
- keep children away from the knife