

USE

- Manual machine intended for cutting tiles made of CERAMIC, DOUBLE-FIRED CERAMIC, SINGLE-FIRED CERAMIC, STONEWARE.

CUT

- Lean the tile against the graduated rod and read the cut length directly on it (Picture 1).
Go ahead with the glaze cutting by properly and evenly pushing forward the tile along its whole length (Picture 2).

BREAKING

- Separate the tile by pressing it gradually with the breaking foot placed at the limit stop (forward) inside the double sliding track. During this operation one should clasp both handle and double track. Do not split the tile at a **single blow** (Picture 3).
In case of diagonal cuts, make sure that the breaking foot is completely placed on the tile.
In order to obtain separations of small sections one should put the foot at the opposite end of the tile (Picture 4).

USE OF THE SQUARE (optional in the BASIC)

- It is possible to adjust cut inclination from 0° to 45° by means of a centimetre square for diagonal cuts.

IN ORDER TO LOCK THE CUTTING SQUARE (PICTURE 5) USE:

- SEAT A for cuts from 0 to 14 cm.
- SEAT B for cuts from 7 to 20 cm.

